
Laser Sight

Model: GM-1042A

USER MANUAL




Thank you for purchasing this Laser Sight Product. Please read this manual carefully before use and keep it for future reference!!

Features:

- 1. LR44 battery x2.
- 2. Compact, lightweight and portable design.
- 3. Fit for universal railed mounted pistol.

Structure Overview:



Specifications:


Wavelength	Red: 650nm
Battery Source	LR44 cell battery x 2
Max Output Power	<5mW
Waterproof Rating	IPX4
Weight	50 g
Running Time	1 hrs

Delivery Sets:


Laser Sight x 1 Allen Wrench x 1 LR44 Battery x 2 Metal Sheet x1 User Manual x1

Operating:

- 1. Press the switch button to turn the laser on.
- Press the switch button again to turn the laser off.
 Ambidextrous On/Off switches on both sides.




Mounting:



Zero Adjustment:

- 1. Fix the laser sight to the barrel on a firearm.
- 2. Place the firearm in a vise or on a shooting bench.
- 3. Place a target about 30m away.
- 4. The next step assumes that the firearm's iron sights or other sighing system is correctly zeroed for 30m. If not, turn the laser of and fire 5 rounds at the target to see the point of impact grouping. If necessary, adjust your sights to the correct point of impact.



5. Take aim again using the exact same sight picture as in step#4. Turn on the laser sight and you will see the difference in distance between the laser dot and the real point of impact. To adjust the laser to be point of impact the windage and elevation will need to be adjusted. Rotating the windage and elevation with Allen wrench to adjust the laser.

6. Now use the laser sight, aim at the target, and shoot another group of 5 rounds. If the point of the laser is near the points of impact, then the Zero adjustment has been accomplished.

Warranty:

This product is free from defects in materials and workmanship. Within 15 days after receipt, any defective product will be offered free replacement by the manufacturer unconditionally. We will repair or replace, at its option and without charge, any product or part which is found to be defective under normal use and service with 12 months counting from the date of purchasing with the proof of purchase. This warranty does not cover normal maintenance and service and does not apply to any product or part which has been subject to modification.

Warning:

Before beginning the adjustment process, insure that your weapon is unloaded and there is no ammunition in the chamber.

During laser alignment make sure to always keep your weapon pointed in a safe direction away from others and never place your finger on the trigger,

Direct viewing of the laser is hazardous to the eyes.

Never look directly into the laser beam.

Never point laser beam at a person.

Do not allow children to use laser sight unless under adult supervision.



Laser beam is forbidden to shoot eyes and skin directly, blindness and burn will be caused.
